

How to put on Maestro EP:

1. Put on hygiene glove.



2. Before inserting hand into Maestro EP, the wrist strap should be secured at desired tightness. Larger strap should be loosened to get hand into the glove.



3. Slide hand into the glove using the pull loop.



4. Align the housing on top of the forearm.



5. Use the large strap to secure the housing and close the strap around your forearm.



6. Adjust fingertip area as needed to secure finger caps are appropriately placed.



7. Repeat steps 1 through 6 on the other hand.



To remove the gloves, undo the large strap and loosen. Grab the gloves by the fingertips and slide hand out.

