

Headset and glove wire set up:

1. Gather Maestro EP gloves, USB hub, zip tie, wire wrap, and headset of choice
2. Lay out USB cords from gloves next to headset's cord with all exit points roughly lined up



3. Mark or grab the glove cords roughly 36 inches down from where the cord exits the glove housing (if measuring tape is not available, use twice the length of the the gloves themselves)
4. Mark or grab the headset cord roughly 16 inches down from where the cord exits the headset. After completing step 3 and 4, your layout should look roughly like this:



5. Hold these three points together and grab wire wrap



6. Uncoil the wire wrap and wrap the wire wrap around all 3 cords
7. Secure the top of the wrapped cords with zip tie to ensure the wire wrap and cords do not come undone



8. Continue wrapping the wire wrap along the rest of the length of the cords and wrap
9. Plug USB from both gloves into USB hub provided in package
10. Snip zip tie to desired length
11. Plug USB hub into computer